

INSTRUCTIONS

1

LAY THIS GUIDE
ON THE GROUND
AND PLACE
COMPASS ON THE
BLACK BOX, THEN
ROTATE THE
SAT-MAT TO
ENSURE THE
COMPASS NORTH
ARROW ALIGNS
WITH RED ARROW
ON THIS SAT-MAT

2

POSITION YOUR
TRIPOD AS
PHOTO BELOW



THE
SATMAT
BY
QuickSAT

For
UK Satellite 2

