

1. Press MENU key
2. Press the down arrow twice to highlight the SYSTEM SETTING menu
3. Press the OK button
4. Now the First line titled SPRACHE is highlighted in yellow
5. Press OK
6. Press the left arrow twice so that ENGLISH appears selected
7. Press the EXIT button twice
8. Press the UP ARROW twice to navigate to the EDIT CHANNEL menu
9. Press the OK button
10. Now the First line titled TV CHANNEL LIST is highlighted in yellow
11. Press OK
12. Press the LEFT ARROW and scroll through until EASYFIND LNB appears in the top selection
13. Now use the UP and DOWN ARROWS to highlight in yellow 0003 ASTRA 28.2E
14. Press OK
15. Press EXIT button 4 times to return to the NO SIGNAL screen
16. Now press the INFO button twice
17. The top line should read CHANNEL ASTRA 28.2E
18. Now press the RED (V.FMT) button
19. Your LNB will start to flash RED
20. Ideally, for good quality reception, the signal intensity should be around 80%+ plus and the signal quality 65%+
21. Now starting with the dish facing East move the dish slowly to the right at South east the LED should change colour. Make small movements with the dish left and right and the light should change from RED to AMBER, now all that is required is very small and slow movements of the dish to change the light to GREEN

22. Press EXIT button
23. Press MENU key
24. The EDIT CHANNEL menu should have the arrow next to it
25. Press the OK button
26. Now the First line titled TV CHANNEL LIST is highlighted in yellow
27. Press OK
28. Press the LEFT ARROW and scroll through until ASTRA 28.2E appears in the top selection
29. Now use the UP and DOWN ARROWS to highlight the channel you wish to view and press OK