

Programming the Mini receiver

The QuickSAT mini receiver comes pre-tuned and set up for Astra 28 but should you ever need to reprogram it or set it up for a different satellite follow the procedure below.

1. Make sure the dish is accurately positioned for the satellite you wish to use and is connected to the mini receiver.
2. Press the menu button then use the right arrow to select "Dish Setting".
3. Select "Add Satellite" and press OK
4. Delete the default satellite name "New Sat" and enter the name of the satellite you want to connect to eg. Astra and finish by selecting OK. (Note that the name you use here is purely for your reference and can be anything you like)
5. Press the menu button to exit and then OK to save when prompted.
6. Scroll down to "Blind Scan" and press OK
7. Use the right arrow to select the name of the satellite you just entered in step 4, eg. Astra
8. Scroll down to "Start Search" and press OK
9. When the progress bar at the bottom of the screen reaches the end it will return to the main screen with a "bad signal" message.
10. Press the menu button and use the left arrow to select the "Prog List" entry
11. Select "TV list"
12. Press the menu button and then use the right arrow to select the name of the satellite you entered in step 4 and then press OK. You should now see the list of channels for the satellite.