



Programming Pager Receiver to Transmitter

1. Disarm car alarm system
2. Turn the pager receiver off
3. Press and hold the reset button
4. Turn the receiver on and keep the reset button pressed
5. After 5 seconds the receiver will beep
6. Release the reset button
7. The receiver is now ready to receive the code from the transmitter.
8. Trigger the car alarm system by arming it and then opening a door
9. When the alarm triggers the pager receiver will beep to tell you the code has been received.
10. Turn the receiver off again to end the coding process

Technical Help Line: 01925 650118